

WOODSTAR PRODUCTS, INC.

MINIATURE HORSE STALL INSTRUCTIONS

1. Erect back wall to 48" in height
2. Attach U-channel to back wall at desired stall width.
3. Set 4x4 posts in line with U-channel on back wall. Set posts in concrete or bury 2 1/2 feet down in ground.
4. Attach U-channel to front posts so they line up with U-channel on back wall.
5. Fill partition walls with lumber/grill to equal 48" in height.
6. Attach post caps to face of front posts and fill in with lumber/grill to 48" in height. Attach wall stiffeners if needed.
7. Lay door flat and attach hardware to front of door. Stand door up and attach hinges to post caps. Attach latch receiver to opposite post cap after door is hung to insure proper closure.

Lumber list for 6'x8' stall

Back Wall

8 pcs 2"x6"x6'

Side Wall

If Solid wall 8 pcs 2"x6"x8'

Grilled Wall 6 pcs 2"x6"x8'

Posts

3 pcs 4"x4"x6' treated lumber (2 posts needed every stall after 1st one)

Post Caps

3 2"x6"x4'

Front Wall

6 2"x6"x32 1/2"

OVER PLEASE



1824 Hobbs Drive • Delavan, Wisconsin 53115

Phone: (262) 728-8460 • Fax: (262) 728-1813 • (800) 648-3415 • Web: www.wdstar.com • email: stalls@wdstar.com

